



Neutrino Thunder Duo

1

EN

DE

ES

FR

CH-T

CH-S

JP

Setup guide
Setup-Anleitung
Guía de configuración
Guide d'installation
安裝手冊
安裝手冊
セットアップガイド



For the latest version of this document,
please download the PDF manual at
<http://www.akitio.com/support/user-manuals>



E15-572H1AA012



PN: E15-572H1AA012
July 17, 2013 - v1.1




© 2013 by AKITIO - All Rights Reserved

Akitio assumes no responsibility for any errors or differences between the product you may have and the one mentioned in this document and reserves the right to make changes in the specifications and/or design of this product without prior notice. The diagrams contained in this document are for reference and may not fully represent the real product. Akitio assumes no responsibility for any loss of data or files.

1



2



3

