



Hard Drive Enclosure  
Festplattengehäuse  
Caja Para Disco Duro  
硬碟外接盒

## Taurus Mini Super-S3 LCM

EN

DE

ES

CH



Manual  
Handbuch  
Manual  
使用說明書

For more detailed instructions,  
please download the PDF manual at  
<http://www.akitio.com/support/user-manuals>


E15-570Q1AA031  
4/24/2012 - v1.0



© 2012 by AKiTiO - All Rights Reserved

AKiTiO assumes no responsibility for any errors or differences between the product you have and the one mentioned in this document and reserves the right to make changes in the specifications and/or design of this product without prior notice. The diagrams contained in this document are for reference and may not fully represent the real product.

## Front View - Frontansicht Vista frontal - 正面



- A B** Green = Data access (read/write)  
Red = Error or empty drive bay
- A B** Grün = Datenzugriff (lesen/schreiben)  
Rot = Error oder leerer Laufwerksschacht
- A B** Verde = Acceso a datos (lectura/escritura)  
Rojo = Error o bahía de unidad vacía
- A B** 綠色 = 資料存取中  
紅色 = 硬碟未放入或者硬碟錯誤
- A B** Orange = Rebuilding data  
Orange = Am Wiederherstellen der Daten  
Naranja = Reconstruyendo datos  
橘色 = 重建資料中


### Select

Select menu or mode  
Wähle Menü oder Betriebsart aus  
Seleccionar menú o modo  
選擇設定選單或模式

### OK

Confirm or enter  
Bestätigen oder öffnen  
Confirmar o entrar  
確定或者進入

Rear View - Rückansicht  
Vista posterior - 背面



**USB 3.0**

USB 3.0 SuperSpeed port  
USB 3.0 SuperSpeed Anschluss  
Puerto de USB 3.0 SuperSpeed  
USB 3.0 極速傳連接埠

**DC IN +12V**

Power receptacle  
Netzanschluss  
Toma de alimentación  
電源插座

**FW800**

FireWire 800 ports  
FireWire 800 Anschlüsse  
Puertos FireWire 800  
FireWire 800 連接埠




**HDD A/B**

Hard drive A/B  
Festplatte A/B  
Disco duro A/B  
硬碟 A/B




**eSATA**

eSATA port  
eSATA Anschluss  
Puerto de eSATA  
eSATA 連接埠



1



2



3





2 Select ▶ Select ▶ Select ▶ OK ▶ Select ▶

RAID Mode	Setup
RAID 1	Enter>

**Note:**

When bus-power is insufficient, plug in the external power supply.

**Hinweis:**

Wenn die Stromversorgung über das Datenkabel nicht ausreicht, schließen Sie das externe Netzteil an.

**Nota:**


Quando la alimentación del bus sea insuficiente enchufe la fuente de alimentación externa.

**注意事項:**

當傳輸線供電不足，請使用外接電源。


## Windows

1. Start / Run... → diskmgmt.msc
2. Create NTFS partition



## Mac

1. Applications / Utilities → Disk Utility
2. Create Mac OS Extended (HFS+) partition



For more detailed instructions, please visit our website at  
<http://www.akitio.com/information-center/formatting-external-hard-drives>